


SIRRO 1.0

INSTALLATION INSTRUCTIONS | AUGUST 2024






Mounting base:





Power must be turned off before connecting the cables.

DIMENSIONS




35°/35° 355°

1.0 Loxone

MOUNTING INSTRUCTION

1. Pass the cable from the ceiling through the backplate and fix it in the strain relief.
2. Attach the backplate to the cover with the 4 screws.
3. Mount the backplate on the ceiling with screws (screws are not included).
4. Put the LED module in the inner part and fix it with the spring.
5. Click the inner part back into the outer part.
6. **POWER CONNECTION**
   Connect the wires to the connectors.
   Input voltage 20-28V.



7. Insert the assembled part in the cover.

This fixture only works with Loxone TREE.

works with Loxone


PB19-010-469-0B_v0


WEVER & DUCRÉ
LIGHTING


WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com

SIRRO 1.0

INSTALLATION INSTRUCTIONS | AUGUST 2024







DISMOUNTING AND RECYCLING INSTRUCTIONS
Light source

1. Remove the assembly set and LED module from the cover and disconnect the wires..
2. Pull out the inner part and loosen the lamp spring to remove the LED module.
3. Push at the three points to loosen the front ring.
4. Unscrew the light source to remove it.

The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.



This luminaire contains a light source with the energy class F.

WEVER & DUCRÉ
LIGHTING

WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com