

RON


INSTALLATION INSTRUCTIONS | JULY 2024






Power must be turned off before connecting the cables.

DIMENSIONS






2.0 LOXONE

MOUNTING INSTRUCTION

1. Remove the inner parts of the fixture.
2. Put the LED modules in the inner parts and fix them with the spring.
3. Click the inner parts back into the outer part.
4. Make a hole in the ceiling according to the prescribed dimensions.
5. **POWER CONNECTION**
   Connect the wires to the connectors.
   Input voltage 20-28V.



6. Push the springs upwards and insert the fixture in the ceiling hole.


This fixture only works with Loxone TREE.


works with Loxone


PB19-010-467-0B_v0

WEVER & DUCRÉ
LIGHTING

WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com







DISMOUNTING AND RECYCLING INSTRUCTIONS
Light source

1. Remove the fixture from the ceiling and disconnect the wires.
2. Pull out the inner part(s) and loosen the lamp spring(s) to remove the LED module(s).
3. Push at the three points to loosen the front ring(s).
4. Unscrew the light source(s) to remove it/them.

The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.



This luminaire contains a light source with the energy class F.

WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com