


CENO SURFACE


INSTALLATION INSTRUCTIONS | SEPTEMBER 2025








Mounting base:




DIMENSIONS



1.0 LOXONE

MOUNTING INSTRUCTION

1. Remove the mounting base from the luminaire by loosening the socket screws.
2. Mount the mounting base on the ceiling with screws (screws are not included).
3. **POWER CONNECTION**
   Input voltage 20-28V.



4. Attach the luminaire to the mounting base with the screw opposite side first and tilt towards the ceiling.
5. Fix the luminaire on the base with the socket screws.


WEVER & DUCRÉ
LIGHTING

WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com

PB19-011-XXX-00_v0

CENO SURFACE

INSTALLATION INSTRUCTIONS | SEPTEMBER 2025



DISMOUNTING INSTRUCTION
Light source & loxone box

1. Loosen the socket screws and disconnect the wires to remove the fixture from the mounting base.
2. Remove the loxone box.
3. Dismount the lens holder and lens.
4. Loosen the screws and disconnect the wires to remove the light source.

The loxone box can be replaced by the end user.

The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.

This luminaire contains a light source with the corresponding energy class:

colour temperature	Energy class
2700K/3000K	A↑G E
2000-3000K	A↑G G

Use green electricity to light up your luminaire.

WEVER & DUCRÉ
LIGHTING

WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com