


PLANO PETIT

INSTALLATION INSTRUCTIONS | AUGUST 2026






For this product, the cable with a plug that comes with the LED module is not needed. Please remove it first and then use the LED module.





Mounting base:

1.0




2.0






Power must be switched off before connecting or disconnecting the cables.

DIMENSIONS



1.0 LOXONE




2.0 LOXONE

MOUNTING INSTRUCTION

1 POWER CONNECTION

Input voltage 20-28V.



2 Mount the base on the ceiling with screws (screws are not included).

3 Fix the LED module(s) in the fixture body by turning it/them a quarter clockwise.

4 Connect the plugs between the LED module(s) and the mounting base.

5 Click the fixture into the mounting base.

This fixture only works with Loxone TREE.


works with Loxone


WEVER & DUCRÉ
LIGHTING


WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com

PLANO PETIT

INSTALLATION INSTRUCTIONS | AUGUST 2026







DISMOUNTING INSTRUCTION
Light source & driver

1. Hold and turn the front ring a quarter counter clockwise to remove the LED module(s) and disconnect the wires.
2. Remove the luminaire from the ceiling
3. Push at the three points to loosen the front ring and lens.
4. Loosen the screws to remove the light source.
5. Disconnect the wires and remove the loxone box.

The light source is replaceable by Wever & Ducré or by a professional with explicit authorisation. For more information please contact your local Wever & Ducré customer service point.

Use green electricity to light up your luminaire.

WEVER & DUCRÉ
LIGHTING

WEVER & DUCRÉ BV
Spinnerijstraat 99/21, 8500 Kortrijk, Belgium
weverducre.com