

# **DEEP ADJUST trimless**


**INSTALLATION INSTRUCTIONS | NOVEMBER 2022** 



disconnected from the mains. The driver can only be powered when the luminaire/LED module is already connected. Disregarding this instruction might damage or even destroy the luminaire/LED module. powered off before



### **DIMENSIONS**




#### MOUNTING INSTRUCTION

- Make a hole in the ceiling according to the prescribed dimensions.
- Install the plasterkit into the hole (please see the page 2 for the detail).


## POWER CONNECTION

LED Always use a driver according to the specifications of the LED module.

## Single connection



### **Multiple connection**



# PAR16




#### **Multiple connection**




## Single connection

**MR16** 



#### **Multiple connection**



Push the luminaire in the plasterkit hole.


Driver must be


connecting cables.


# **DEEP ADJUST trimless**


INSTALLATION INSTRUCTIONS | NOVEMBER 2022


#### Install the plasterkit into the ceiling hole.


























# **DEEP ADJUST trimless**

INSTALLATION INSTRUCTIONS | NOVEMBER 2022





- Push in the slot of the spring clip and pull it out.
- 2 Unplug the LED module and remove it from the luminaire.
- 3 Push at the three points to loosen the front ring.
- 4 Take out the lens and unscrew the light source to remove it.



The light source is replaceable by an authorized professional.

For advice contact your Wever & Ducré customer service contact point.



This luminaire contains a light source with the energy class D.