

STREX MODULE

INSTALLATION INSTRUCTIONS | DECEMBER 2022



STREX MODULE

INSTALLATION INSTRUCTIONS | DECEMBER 2022





DISMOUNTING AND RECYCLING INSTRUCTIONS

Light source

Loosen the screws and remove the backplate.

2 Remove the light source by removing the wires from the clamps.



The light source is replaceable by an authorized professional.

For advice contact your Wever & Ducré customer service contact point.



This luminaire contains a light source with the energy class F.